



SOFTWARE RELEASE NOTE 3.9

Software Revision:

- ▶ 3.9

Issued:

- ▶ November 20, 2014

Highlights of Changes

New Features/Improvements:

- ▶ TSD - Added reboot command for field technician debug.
- ▶ ALL - Restrict the SNMP community string "public" as read-only user.
- ▶ ALL - Added support to allow all user interfaces to view the status of software download.

Product Additions/Obsolescence:

- ▶ None.

Bug Fixes:

- ▶ I-HUB - Fixed alarming condition not clearing properly.
- ▶ I-HUB - CLI interface change to restrict switching menu between IHUBs within IHUB menu when monitoring multiple IHUBs.
- ▶ ALL - Fixed the CLI channel mode help description.
- ▶ ALL - Improving inter process communication performance to better support I-HUB 1-way communication under heavy load configuration.
- ▶ Updated MIB files.

Service & Support

Contact ATX Networks

Please contact ATX Technical Support for assistance with any ATX products.

OPTICAL TRANSPORT TECHNICAL SUPPORT

Tel: (408) 227-3400

▶ Press 4 for **Technical Support for Optical Transport Products (ChromaFlex, I-HUB, Chromadigm, TranScend)**

Email: opticalsupport@atxnetworks.com

CUSTOMER SERVICE

InnoTrans Communications Inc.

(a Division of ATX Networks)

5850 Hellyer Avenue

San Jose, CA 95138 USA

Tel: (408) 227-3400

▶ Press 4 for **Customer Service**

Fax: (408) 227-3403

Web: www.atxnetworks.com

Email: opticalsales@atxnetworks.com

Changes affect all product lines unless otherwise noted (CD Chromadigm, TSD TranScend, CF ChromaFlex, I-HUB).

GUI: Graphical User Interface over HTTP, CLI: Local interface with handheld client.
See [firmware upgrade instructions](#).

Although every effort has been taken to ensure the accuracy of this document it may be necessary, without notice, to make amendments or correct omissions.
Specifications subject to change without notice.



5850 Hellyer Avenue, San Jose, CA 95138 USA
Tel +1 (408) 227-3400 Fax +1 (408) 227-3403
www.atxnetworks.com opticalsupport@atxnetworks.com