

## F MINI CABLE COMPRESSION CONNECTOR (MPF-C / MPF-CQ)

### Step 1:

Set the MP-NBCT compression tool.




### Step 2:

Strip cable to standard 1/4" - 1/4".

Fold all braid and outer foil back.

Optional: outermost foil layer may be removed if it eases installation. Avoid removing any braid.





#### IMPORTANT:

Ensure center conductor length is between 3/16" and 1/4". Over extending center pin length **WILL DAMAGE CONNECTORS**. Under extending will make intermittent electrical contact.

### Step 3:

For an easier fit, slide the MPCPT cable prep tool over the dielectric and twist.

Prepping cable with MPCPT is **strongly** recommended when using tri and quad shield cable. The MPCPT should fully bottom-out between inner foil and braid layers to ensure connector will go on with minimal effort.



Use MPCPT to check center conductor length.

### Step 4:

Insert center conductor into connector receptacle and apply pressure with a twisting motion until cable is fully inserted, and center pin of connector is fully extended. Do not apply excessive force, as this will damage the connector and over extend the pin.

Inspection before compressing:

- no braid should appear outside of connector body (likely indicates connector not inserted fully)
- center pin of connector should:
  - MCX or BNC: stop approx. 1/8" before face of connector, so that it is **NOT** visible when looking from the side.
  - F: stop approx. 1/8" past face of connector so that it **IS** visible when looking from the side.



### Step 5:

Carefully insert F nut over the compression tool plunger and pull cable down into cable jaws.



## Step 6:

Fully compress tool until it releases and gently remove connector.



## Step 7:

Finished terminated cable.

Inspection:

- Compression collar should **NOT** rotate to ensure mechanical strength of connection.



## Service & Support

### Contact ATX Networks

Please contact ATX Technical Support for assistance with any ATX products. Please contact ATX Customer Service to obtain a valid RMA number for any ATX products that require service and are in or out-of-warranty before returning a failed module to the factory.

#### RF & OPTICAL TECHNICAL SUPPORT

Tel: (905) 428-6068

Toll Free: (800) 565-7488 (USA & Canada only)

▶ Press \*3 for **Technical Support**

▶ Then press 2 for **RF & Optical Products (MAXNET, SignalOn, HFC Enhance, PCI Filters, Q-Series, FLEXNET, SCN, SMAC FiberLinx)**

Email: [rfsupport@atxnetworks.com](mailto:rfsupport@atxnetworks.com)

#### CUSTOMER SERVICE

ATX Networks

1-501 Clements Road West

Ajax, ON L1S 7H4 Canada

Tel: (905) 428-6068

Toll Free: (800) 565-7488 (USA & Canada only)

▶ Press \*1 for **Customer Service**

Fax: (905) 427-1964

Toll Free Fax: (866) 427-1964 (USA & Canada only)

Web: [www.atxnetworks.com](http://www.atxnetworks.com)

Email: [support@atxnetworks.com](mailto:support@atxnetworks.com)

## Warranty Information

All of ATX Networks' products have a 1-year warranty that covers manufacturer's defects or failures.

Although every effort has been taken to ensure the accuracy of this document it may be necessary, without notice, to make amendments or correct omissions. Specifications subject to change without notice.

SignalOn® Series, MAXNET®, HFC Enhance®, PCI Filters®, Q-Series® & FiberLinx® are registered trademarks of ATX in the United States and/or other countries. SMAC<sup>SM</sup> is a service mark of ATX in the United States and/or other countries. Products or features contained herein may be covered by one or more U.S. or foreign patents. Other non-ATX product and company names in this manual are the property of their respective companies.



1-501 Clements Road West, Ajax, ON L1S 7H4 Canada

Tel +1 (905) 428-6068 Toll Free +1 (800) 565-7488

Fax +1 (905) 427-1964 Toll Free Fax +1 (866) 427-1964

[www.atxnetworks.com](http://www.atxnetworks.com) [support@atxnetworks.com](mailto:support@atxnetworks.com)